



Faster, Better, Easier

# Beachcrete™

**Creating exposed pebble paths and slabs**

**Perfect for**

- ✓ **BBQ Areas**
- ✓ **Pathways**
- ✓ **Patios**
- ✓ **Garden Steps**



## 1 Mix

Add 1.6l water per bag and mix for approx. 3 min.



## 2 Pour

Pour mix into prepared boxed area.



## 3 Screed

Screed mixture until evenly spread.



## 4 Trowel

Trowel area and wait for 1.5 – 2 hours.



## 5 Expose

Immerse a 'dense foam' roller in water and roll across slab until surface slurry is removed.



## 6 Acid wash

After 24 hours, mix a 4:1 water to hydrochloric acid solution and pour it evenly on the surface. Rinse with water afterwards.



## 7 Seal

Wait 7 days and when concrete is dry, seal the surface for protection.





Faster, Better, Easier

# Items you require for your project



- Boxing
- Screed
- Shovel
- Trowel
- Rubber mallet
- Concrete edger (optional)
- Broom
- 'Dense foam' rollers (10mm thick)
- Hydrochloric acid
- Measuring jug/bucket

## Top Tips

### Monitoring surface hardness

Before you start to expose the pebbles, test the surface by gently pressing your finger against it. It is ready at a semi-set stage and should feel firm, but still a bit soft.

### The right roller

Use a dense foam roller with a thickness of 10mm to expose the pebbles. Only this type of roller absorbs the cement slurry sufficiently and achieves a great result.

### Preparing for acid wash

Pour the acid into the water (not vice versa) to avoid splashing. Wear protective gloves and glasses when mixing the hydrochloric acid solution.

[www.easymixsales.com.au](http://www.easymixsales.com.au)



Watch the how-to video